PORTABLE DISHWASHER

MODELS:

MDC4809PAB1 (Black)
MDC4809PAW1 (White)

© 2013 Maytag
Part No. W10607451 Rev. A

DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W10255025	Instructions, Installation
	W10438327	Use and Care Guide, English/French
	W10438305	Use & Care Guide, Spanish
	W10490734	Energy Guide
	W10321979	Tech Sheet, English
	W10321980	Tech Sheet, French
2		Arm, Hinge
	W10274922	Left Hand
	W10274921	Right Hand
3	8268983	Brace, Door Cross
4		Panel Front
	W10299779	Black
	W10299778	White
5		Access Panel
	W10441003	Black
6	489470	Screw
7		Fastener
	W10503548	Black
8	304392	Screw
9		Shroud, Caster
	W10270163	Black
	W10270155	White
10	W10001330	Screw
11	W10255097	Protector

CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

Illus. No.	Part No.	Description
1		Console Assembly (Includes Active Overlay & Insert)
	W10584818	Black
	W10584819	White
2	W10274884	Bolt, Latch
3	W10540255	Control, Electronic
4	W10274880	Switch, Door
5		Latch Assembly
	W10290198	Black
	W10290199	White
6	W10401190	Box, Connector
7	W10348413	Screw
8		Handle, Latch
	W10240154	Black
	W10240155	White
9	W10372484	Brace, Connector
10	8524472	Actuator, Latch
11	W10274837	Pipe, Light
12	W10274842	Tree, Button

INNER DOOR PARTS



INNER DOOR PARTS

Illus. No.	Part No.	Description
1	W10177098	Screw
2	8269296	Seal, Door/Console
3	W10254547	Inner Door Assembly (Also Order Item 6)
4	W10482094	Cover, Dispenser
5	W10177098	Screw
6	W10475829	Gasket, Vent
7	W10254548	Deflector, Vent (Also Order Item 6)
8	W10428215	Dispenser Assembly
9	W10462232	Bracket, Dispenser
10	W10444715	Wiring Harness
11	W10524922	Cap, Rinse Aid

FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

Illus. No.	Part No.	Description
1	8268892	Lever, Overflow Switch
2	8531412	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10508676	Nut, Inlet (Also Order Item 4)
6	371505	Clamp, Hose
7	W10195047	Fill Valve Assembly
8	304392	Screw
9	W10102495	Switch, Overfill Control
10	W10175383	Standpipe, Overfill
11	8268913	Float, Overfill Control

TUB AND FRAME PARTS



TUB AND FRAME PARTS

Illus. No.	Part No.	Description
1	W10266934	Tub Assembly (Includes Heater Assembly)
2	W10354998	Coupler Assembly
3	W10524469	Seal, Tub
4	8559928	Frame, Assembly
5	W10341745	Screw
6	3373199	Panel, Top
7	304428	Screw
8	8268961	Sleeve, Friction
9	8268990	Bushing, Door Spring
10	8559933	Caster
11	W10165274	Screw
12	W10337934	Spring, Door Balance
13	8270016	Wheel And Mount Assembly
14	W10219671	Cord, Power
15	W10219673	Housing, Hose
16		Shell Assembly
	W10356266	Black
	W10356267	White
17	3378595	Clip, Thermostat
18	W10339474	Thermostat
19	8580309	Strike, Latch
20	W10219682	Protector, Edge Divider
	W10254751	Protector, Edge Short
21	W10254672	Adapter, Faucet
22	W10339699	Shield, Thermostat
23	3378109	Saddle, Hose
24	W10271702	Support, Bottom
25	W10304228	Leveler, Leg
26	3378128	Washer, Pronged Cup
27	W10328716	Bar, Blocker
28	3400014	Screw, Grounding

PUMP AND MOTOR PARTS



PUMP AND MOTOR PARTS

Illus. No.	Part No.	Description
1	8534952	Accumulator Assembly
2	8283527	Shield, Motor
3	W10348405	Screw
4	8572618	Sump with Seal
5	8268375	Check Valve, Sump Assembly
6	W10083957	Chopper Assembly
7	9741232	Screw
8	8531857	Protector Inlet
9	W10239404	Motor Assembly
10	3400217	Screw
11	W10084567	Screen, Separation
12	W10237169	Sump & Motor Assembly
13	W10300599	Tab, Sump
14	8533949	Nut
15	W10348269	Pump, Drain
16	W10142656	Volute, Back (Also Order Item 19)
17	W10334457	Capacitor
18	W10239401	Motor
19	8531017	Impeller Kit
20	8578828	Thermistor

UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

Illus. No.	Part No.	Description
1	W10254531	Feed Tube Assembly
2	W10349488	Screw
3	3385160	Hanger
4	W10258149	Manifold
5	3385159	Mount, Sprayarm
6	8268433	Seal, Sprayarm
7	8562095	Probe, Manifold
8	W10082841	Sprayarm, Upper
9	3400919	Fastener, Push-In

HEATER PARTS



HEATER PARTS

Illus. No.	Part No.	Description
1	W10134009	Heater Element Assembly (Includes Item 2)
2	717273	Washer, Rubber
3	8268548	Nut, Heater Element
4	8269262	Bracket, Heater Support
5	W10343251	Shield, Heater Probe NOTE: If heater element is removed, it must be replaced.

UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Illus. No.	Part No.	Description
1	W10164198	Dishrack, Upper
2	8565925	Stop, Track (Non-Removable)
3	8575281	Mount, Wheel Assembly
4	3385089	Track, Dishrack
5	W10306228	Track, Spacer

LOWER RACK PARTS



LOWER RACK PARTS

Illus. No.	Part No.	Description
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	W10438331	Silverware, Basket Assembly

LOWER WASHARM PARTS



LOWER WASHARM PARTS

Illus. No.	Part No.	Description
1	W10330588	Wash Arm Assembly
2	8268317	Cap, Internal Rear Feed
3	8268340	Bearing, Lower Sprayarm
4	W10077898	Hub, Lower Sprayarm

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

Illus. No.	Part No.	Description
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White
	4392900	Biscuit/Bisque

POWER CORD KIT

Illus. No.	Part No.	Description
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

Illus. No.	Part No.	Description
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

Illus. No.	Part No.	Description
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis